Brand	Cosori	Version	01.01	Size	76.2*76.2 mm
Product Name	Original Electric Gooseneck Kettle			Colors CMYK	
Model	CO108-NK-RBB	Date	12/16/2019		
Bonus Item	2 x Coasters				

We're here to help!

If you encounter any issues or have any questions regarding your new product, please contact our helpful Customer Support Team. Your satisfaction is our goal!

Support Hours
Monday–Friday
9:00 am–5:00 pm PST/PDT

Email: support@cosori.com
Toll-Free: (888) 402-1684

COSORI

Back

COSORI

Join the **Cosori Cooks Community** on Facebook!

facebook.com/groups/cosoricooks

Share your unique recipes and ideas with others, or discover new recipe ideas every week, both from us and the Cosori community.

Snap, tag, and hashtag away!

@cosoricooks | #iCookCosori

Front

DESCALING YOUR KETTLE

Limescale is formed by minerals in the water and is harmless. Limescale may accumulate at the bottom of the kettle due to poor water quality.

1. Unplug kettle. Pour out water and allow kettle to cool.



2. Fill kettle with ½ US cup / 118 mL of vinegar. You can also squeeze the juice from half a lemon.



3. If kettle has thicker scale buildup, scrub inner walls with a non-scratch scrub sponge.

***Note: Do not** use steel wool.*



4. Add 2 US cups / 473 mL of water. Boil mixture.



5. Pour out mixture, then wipe off any remaining scale with a non-abrasive cloth, sponge, or brush.



Inside