

HURRAN



Tools you may need





*Scan the QR code or search HURRAN on YouTube to watch the installation video.

*If you need installation assistance, replacement parts or have questions regarding our warranty, please email our customer service team: hurranserviceteam@gmail.com We will reply within 24 hours


*To ensure that your installation proceeds smoothly, please read these instructions carefully before you begin.

*Thank you for choosing HURRAN.

Installation


Prior to installation: Shut off water supply. Remove old faucet.
Clean sink/countertop surface in preparation for new faucet.

1




Pre-drilled Hole Diameter
A=7/8"-1 3/8"
B= 7/8"-1 3/8"
Center distance: 4"

2




Allign and press into place.

3




Insert the faucet through sink.

4




Screw the nut onto shrank, leaving approximately 0.12" (3mm) between the ring and the sink.

5




Screw on the lock nut hand tight.
Do NOT over tighten.

6




Remove excessive putty, adjust slightly the position of faucet.

7




Connect and tighten the supply hoses.

Note 1. Open the hot and cold water supply angle valve to check whether there is leakage at the connection, If the connection leaks, use a tool to retighten the nut




Note 2. If the water flow is too small during use, you can manually disassemble the bubbler shell for cleaning and reuse, or replace the optional




Pop-up Drain Installation


1 Preparing the pop-up assembly

- □ Remove the bottom gasket (N) and nut (O) from the top gasket (L) and pop-up body (M).
- □ Attach these pieces together by pushing the bottom gasket (N) down into the top of the nut (O) and twisting together.




2 Installing the pop-up body

- □ Insert the pop-up body (M) into the sink. Ensure that the top gasket (L) rests securely between the top of the sink and the top of the pop-up body (M).




3 Securing the pop-up body

□ From underneath the sink, screw the bottom gasket (N) and nut (O) assembly onto the pop-up body (M) by twisting clockwise until secure.



4 Close the drain and fill the sink with water. Check for leaks. If water is leaking from the drain, refer to step N or O.



Product List

