

NICE TO MEET YOU!

Thank you for purchasing the DitooPro, the best desktop gadget from Divoom. With DitooPro & its companion APP, you can create pixel art designs and interact with the largest pixel art community, as well as to enjoy its great audio. DitooPro is capable of many daily functions, and it can learn more via software updates.

WHAT'S INCLUDED?

- DitooPro
- User manual
- USB Type-C charging cable



DitooPro



User manual



USB Type-C
charging cable

Thank you for purchasing a Divoom product! Please read this manual carefully. You can also visit www.divoom.com to learn more about our other products. Due to the nature of the technology product, the information on this manual is subject to change without prior notice. If you have any questions, please contact the Divoom customer support.

PRODUCT DETAILS

1. 'm' button

Press: Enter/Exit menu system

Hold: Turn On/Off the keyboard backlight

2. '+' button

Press: Increase volume

Hold: Increase brightness

3. '☼' Lighting button

Press: Change light function

Hold: Change light effects

4. '⏮' button

Press: Previous song

Hold: Last light effect

5. '-' button

Press: Decrease volume

Hold: Lower brightness

6. '⏭' button

Press: Next song

Hold: Next light effect

7. Lever


Short pull: Play/Pause

Long pull: Start voice memo recording

8. Audio source button

Short pull: Switch between the different audio sources

Double press: Disconnect
Bluetooth connection



9. Battery indicator

Press any button to check the battery status

10. Bass port

11. Rear port flap

12. Reset pin hole


13. USB-C charging port

14. ON/OFF button

Hold: Power ON/OFF speaker

15. TF card slot

Playback music from TF card



HOW TO USE DITOOPRO'S MENU FUNCTION?

1. Short press the (m) menu key to enter the menu system;
2. Use the (←)(→) keys to switch between music/pixel coloring/tools/alarm clock/game;
3. Pull down the joystick to confirm the option, and short press the (m) menu key to exit the current menu function.

【Music】

Pull down the joystick to enter the music function, press (←)(→) keys to switch to Bluetooth or TF card mode, pull down the joystick to confirm.

【Pixel coloring】

Pull down the joystick to start coloring, press the (+)(-)(←)(→) key to move the icon, pull down the joystick to fill in the selected area until the color of the pattern is filled, then enter the next pixel image coloring.

*Press the (sun icon) key to view the complete pattern prompt

【Tool】

Pull down the joystick to enter the tool, and press the (←)(→) keys to select tools: scorer, timer, countdown, noise detection

【Alarm clock】

Pull down the joystick to enter the alarm clock settings, press the (+) (-) keys to set the clock and minute time respectively, pull down the joystick to confirm and start the alarm clock*How to cancel alarm: Enter the alarm clock setting interface and long press the joystick to delete the set alarm clock

【Game】

After selecting the game menu function, press the (←)(→) keys to switch between slot machine/dice/magic black 8 ball/pinball/flying bird/snake/pixel racing, etc, and

pull down the joystick to confirm and start the game. During the game, short press the (+)(-)(←)(→) keys to move up and down, and pull down the joystick to confirm.

HOW TO CONNECT THE SPEAKER?

Download mobile application

Search 'Divoom' application for both iOS and Android systems.

*Please grant all privilege requests prompted by the APP.

For Apple iOS system, connect 2 Bluetooth


Search and connect the 'DitooPro-audio' in Bluetooth settings for music, then search and connect the 'DitooPro-light' in the Divoom APP for controlling the screen.

For Android system, connect 1 Bluetooth

Search and connect the 'DitooPro-light' or 'DitooPro-audio' in APP to control the music and screen.



Download the Divoom from the App Store and Google Play™



FOR APPLE IOS





FOR ANDROID

60 SECONDS VOICE MESSAGE FUNCTION

1. Pull down the joystick and hold it for 3 seconds. After the message pattern appears on the screen, release the joystick to start recording messages;
2. Pull down the joystick to end recording, and pull down the joystick again to play the message.

*The voice message will be automatically deleted after playing.




HOW TO SET ALARM CLOCK MANUALLY?

1. After pressing the (m) button, use the (←)(→) keys to switch to the alarm clock, and pull down the joystick to enter the settings;
2. First press the (+)(-) keys to set the clock time, pull down the joystick to confirm; then press the (+)(-) keys to set the minute time, pull down the joystick, and a ticked alarm clock icon appears to indicate that the alarm clock is set successfully.

*How to cancel alarm: Enter the alarm clock setting interface and long press the joystick to delete the set alarm clock. A crossed alarm clock icon appears to indicate successful deletion.

*DitooPro only supports 1 set of manual alarm clocks. If you need more alarm clocks, please use Divom App to set them.




HOW TO PLAY THE TF CARD AUDIO?

1. Insert the TF card into the TF card slot, and the speaker will automatically enter the TF card mode;
2. Short press the mode button ⑧ to quickly switch the playback mode;
3. Switch the mode: short press the (m) menu button, pull down the joystick to enter "music" menu. Use the (←)(→) keys to switch to TF card mode, and pull down the lever to enter.

*In music mode, please use the keyboard buttons and joystick controls to play music


*MP3/WAV/FLAC are the only supported file formats. The maximum supported capacity is 64GB.



HOW TO CHARGE?

- 1.Insert the USB Type-C cable into the speaker.
- 2.Press the power button if you want to check the battery percentage.
- 3.When charging, the indicator light will lit. Upon 100% charged, the indicator will turn off.

*Please use a 5V--- 2A charger, and do not use higher voltage charger.



PRODUCT SPECIFICATION

Dimension : 114.2 x 90 x 121.2mm

Weight : 533g

Speaker size : 48mm

Output power : 15W

Frequency response : 30Hz-20KHz

Signal-to-noise ratio : 80dB

Playback time : 8hrs

(tested under moderate volume with controlled environment)

Battery capacity : 5000mAh

Battery voltage : 3.6V

Battery charge time : 4hrs

Charge : 5V--- 2A

Wireless range : 10M/33ft

Bluetooth compliant : 5.0

SAFETY GUIDE

Please read the following instructions carefully:

1. Please follow our product installation about operation instructions.
2. Always place the speaker on a smooth and stable surface.
3. Please place the speaker on an open area for the best sound quality. Do not block the surroundings of the speaker.
4. Do not push any objects into speaker vents or slots. Do not apply any great force on the speaker.
5. Please keep the speaker at a room temperature environment. Do not place the speaker near any heat sources (such as radiators, heat registers, stoves, fire place, or direct sunlight). Do not place the speaker near any open flame source.
6. Do not attempt to service the speaker by yourself. Always refer to the instructions by qualified service personnel.
7. To avoid the risk of electrical hazard, do not expose this speaker to wet surface.

DECLARATION OF CONFORMITY:

 This device meets the essential requirements of the following Directive 2014/53/EU of the European parliament and of the council of 16 April 2014.

 The waste container symbol with the X through it on the device indicates that the device must be disposed of separately from normal domestic waste at an appropriate waste disposal facility at the end of its useful service life.

Please dispose of used batteries properly following local regulations. Do NOT Incinerate. Removal of the rechargeable lithium-ion battery. In this product should be conducted only by a qualified professional.

ROHS This product is in compliance with Directive 2011/65/EU of the European Parliament and of the Council of July 1 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation, changes or modifications not expressly approved by the party responsible for compliance could void the user's warranty to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential Installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which it can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio ATV technician for help.

WARRANTY INFORMATION

This product is covered by a limited warranty from Divoom. For complete warranty details, visit the website www.Divoom.com.

WARRANTY INFORMATION:

- 1.If you believe your product is defective within the warranty period, please bring the product back to where the product was initially purchased. Alternatively, or within any other questions or concerns, please call customer support at +0755 86290767, or contact us via email at info@divoom.com.
2. If within 12 (24 if required by local law) months of purchase this device or any part thereof is proven to be defective by reason of faulty workmanship or defects in materials, we will at our option repair or replace the same free of charge of labor or materials on condition that similar to the product current condition.
- 3.The sales invoice or receipt with the date and source of purchase must be presented together with the defective unit. We cannot validate the product warranty information without an invoice.
- 4.The warrant does not cover product failures which have been caused by use of accessories other peripheral devices which are not Divoom branded original accessories intended for use with the product.
- 5.The warranty does not cover product failures caused by: modification, repaired, and disassembled by any person who is not authorized by the manufacture.
- 6.The warranty is non transferable. Any defective unit or part shall become property of the manufacture.
- 7.Warranty does not cover any damage caused by misuse, drop, hit or negligent.
- 8.Customer is responsible for the return shipping charges.

PRODUCT WARRANTY CARD

Product name		Serial number	
Purchasing store		Purchasing date	
Owner name		Contact Email	
Address			

Divoom official website: www.divoom.com/www.divoom-gz.com

Divoom warranty Information: <https://divoom.com/policies/refund-policy>

Divoom product FAQ: <https://divoom.com/apps/help-center>

Divoom support Email: support@divoom.com

Divoom support contact number: 0755-86290791

Divoom repair & return address:

Manufacturer: Shenzhen Divoom Technology Limited Corporation

Address: 1st & 2nd floor, Building No.9, Antuoshan High-tech Industrial Park, Sha'er Community, Shajing Subdistrict, Bao An District, Shenzhen, China 518000.